

MegaClean Heavy-Duty Cleaners are a solution that offers an effective alternative to toxic and flammable solvent-based cleaners such as acetone and isopropyl alcohol. Original MegaClean non-flammable, bio-degradable formulation is an ideal spot cleaning solution that easily removes grease, photoresist stains and adhesives, such as tacky mat residues, from most surfaces.

The New MegaClean CT detergent is a low-sudsing, high temperature detergent originally designed for sonic baths and spray applications. Highly effective on slurries and residues, it contains corrosion inhibitors for use with scrubbers.

- Filtered to 1 micron
- Non-flammable
- Bio-degradable
- Water soluble
- Effective at low concentrations

Suggested Use and Dilutions

Heavy-duty cleaning: use a 50% or greater concentration

Suggest 3 to 5 minute dwell or immersion time.
Will require production quality water or IPA rinse.

- Photoresist stains
- Slurry or graphite removal
- Removal of flux from circuit boards
- Ultrasonic baths
- Parts, bearings
- Scuff marks

Medium to heavy cleanup: use 10 to 25% concentration
Will require production quality water or IPA rinse

- Lens
- Floors
- Spot Removal



SPECIFICATIONS

Material:

1 micron filtered detergent and degreaser

Container: HDPE

Sizes:
1 quart with spray pump
1 gallon container
5 gallon pail

Manufactured for use in Controlled Environments

- ISO 5 thru 9 Cleanrooms
- ISO 9001 Certified Manufacturing Facility



Micronova Manufacturing, Inc.
3431 W. Lomita Boulevard
Torrance, CA 90505-5010 USA

Tel: 310/784-6990
Fax: 310/784-6980

SalesInfo@micronova-mfg.com
www.micronova-mfg.com