

Microfiber SlideMop™ Cover



The **Microfiber SlideMop™ Cover** is part of a simple, effective mopping system that can be used in the traditional dip-and-wring method or with a charging method where liquid disposal and/or space saving is a challenge. The microfiber mop head is ideal for fine particle pick-up and features excellent absorption with a large coverage area. Use with Micronova charging system, BucketBinders™, or Modular Cart Systems for optimal overall performance.



Features:

- Highly absorbent microfiber cover, ideal for liquid pick-up, fine particle pick-up, and residue removal
- V-cut pocket allows for easy slide-on application and removal, and compatible with other 16" flat mop frames
- For no-touch option, use with Stainless Steel or Plastic SlideMop™ Adapter (QSM, QPSM)
- For lightweight simple slide-on action, use with Plastic SlimLine™ Adapter (QPSL)
- Durable mop construction; can be laundered and holds up to repeated autoclave cycles

Use With:



SPECIFICATIONS

Materials of Construction:

Cleaning Surface:	80% polyester, 20% nylon
Interior:	100% polyester pad
Dimensions:	5.5 x 16 in (14 x 40 cm)

Mop Properties

Average Values:

Weight (Dry)*	44g
Absorbency (H ₂ O)*	172.1mL/mop
Area Coverage (per saturation)*	72 ft ² , 7 m ²
Volume for presaturation*	400 mL per mop
Autoclavable*	(121°C for 30min)
Reusable	20 times with autoclave cycles
Disinfectant, Cleaning Solution Compatibility	> 6 hours

Reference Test Procedures:

* Micronova Lab Procedure SOP

- Manufactured for use in Controlled Environments
- ISO 5 thru 9 Cleanrooms
- ISO 9001 Certified Manufacturing Facility



Micronova Manufacturing
3431 W. Lomita Boulevard
Torrance, CA 90505-5010 USA

Tel: 310/784-6990
Fax: 310/784-6980

SalesInfo@micronova-mfg.com
www.micronova-mfg.com