

The **PipePlunger™** Tool is a polyester/foam cylinder-shaped sponge tool specially designed to thoroughly clean piping and tubing interiors. The 100% polyester foam interior is covered with a smooth polyester fabric, which provides durable, smooth contact with surfaces, as well as ample soaking material to hold disinfectant and cleaning solution.

Features:

- 100% smooth knit polyester cover ideal for fine cleaning and sanitization
- Stainless steel adapter for long life and durability
- Available gamma-irradiated for aseptic environments
- Autoclavable
- Good chemical resistance to disinfectants and cleaning solutions

- Manufactured for use in Controlled Environments
- ISO 5 thru 9 Cleanrooms
- ISO 9001 Certified Manufacturing Facility
- Minimum Irradiation Dose: 25 kGy

SSU Series stainless steel handles



Adapter to use with SSU Series handles

SPECIFICATIONS

Materials of Construction:

- Adapter:** 304 Electropolished Stainless Steel
Derlin Plastic components
- Covers:** 100% Smooth knit Polyester
100% Polyester foam interior

Dimensions:

- Adapter:**
QDPPT-01: ¾ in (2.5 cm) x 8" (20 cm) length
- Covers:**
PP6-35LIR: 3 in (8 cm) diameter, 5" (13 cm) length
PP6-45LIR: 4 in (10 cm) diameter, 5" (13 cm) length
PP6-65: 6 in (15 cm) diameter, 5" (13 cm) length



Micronova Manufacturing
3431 W. Lomita Boulevard
Torrance, CA 90505-5010 USA

Tel: 310/784-6990
Fax: 310/784-6980

SalesInfo@micronova-mfg.com
www.micronova-mfg.com